

**RECOMMENDED ACCESSORIES:**

Driver and Roll Cage – [CLICK HERE](#)

Pinewood Derby Wheels – [CLIC HERE](#)

Testors One-Coat Spray Paint – [CLICK HERE](#)

Monkey Dust Premium Graphite – [CLICK HERE](#)



**Tools & Supplies Needed**

- Band Saw or Coping Saw
- Electric hand drill or press
- 3/8" Drill Bit for weight holes
- #44 Drill Bit for axle holes
- Sharp Pointed Object (punch)
- 3/8" Tungsten Cylinders or...
- 3/8" Lead wire for weight
- Body Putty / Wood Filler
- Safety Glasses
- Hearing Protection
- Scissors
- Markers
- Sandpaper
- Paint, Accessories and Decals

Standard BSA Axle Holes/Slots

# TOP FUEL

6.75" L x 1.75" W

## TOP

FRONT

REAR

# Derby Monkey Garage

## SIDE

AXLE LINE

AXLE LINE

TO SCALE: 1 SQUARE = 1/4"

3/8" HOLES  
FOR WEIGHTS

[WWW.DERBYMONKEY.COM](http://WWW.DERBYMONKEY.COM)